

The fenders are mounted at the stays of front and rear swingarm. They make the Birdy able to use it daily by keeping the rider clean from water and dirt.

Of course the fenders do not influence the folding size and folding process.

Older Birdys can be upgraded with fenders for caliper brakes. Birdys with V-brakes until year 2000 and for year 2001 can be upgraded with fenders too.

Since year 2002 the Birdy has a new type of front swingarm with a different way of mounting the fender with an additional stay. Also the color will change from silver to black. The fenders for Birdy with SL carrier are available under No. 622300, all other Birdys need the fenders No. 622400.

Scope of Delivery

- 1 x Fender front
- 2 x Nylon washer M5, white, 1mm thickness, OD 22.5 mm
- 1 x washer M5 big)
- 1 x Bolt with round head M5 x 20
- 1 x Front fender stay incl. 2 caps
- 1 x Bolt with black plastic head M5 x 13
- 1 x Self lock nut M5
- 2 x Bolts for fender stay incl. washer and nut M5
- 1 x Plastic spacer black M5, 10mm thickness, OD 15 mm

The rear fender is different for SL carrier (622300) or Birdys with rear fender stay (622400):

- 1 x Fender rear (with Spoiler)
- 1 x Reflector at fender (*only 622300*)
- 1 x Rear fender stay (*only 622400*)
- 2 x Nylon washer M5, white
- 1 x Plastic spacer black M5, 3mm thickness, OD 20 mm
- 1 x Plastic spacer black M5, 10 mm thickness, OD 15 mm (*only 622300*)
- 2 x Washer M5 big
- 1 x Bolt with round head M5 x 16
- 1 x Bolt with round head M5 x 25 (*only 622300*)
- 1 x Bolt with black plastic head M5 x 14
- 1 x Self lock nut M5 (*nur 622300*)
- 3 x Washer M5 (*4 x for 622300*)
- 2 x Bolt M5 x 12

How to mount the fenders

Front fender

Mount front fender with round head bolt, 2 nylon washers and standard washer at the front swingarm.



Mount fender stay with plastic head bolt, nylon and standard washer and self lock nut. Mount fender bolts and fender stay at front swingarm. After adjusting the fender stay tighten the nuts of fender bolts.





Rear fender

Mount rear fender with bolt and nylon plus standard washer at the rear swingarm.



Insert plastic head bolt into rear fender stay and hole in rear fender. Mount nylon washer, standard washer and self lock nut. Mount fender stay with bolts M5 x 12 and washers at dropouts (4-5 Nm).



! To customers: All of the procedures we are about to describe require a certain degree of skill, suitable tools and mechanical attitude. The procedures should be carried out only by your dealer.

! To dealers: Always give this manual to your customer because it contains important information how to use the products.